

## SFIC Cylinder Housing Tailpiece Shortening Instructions

When installing the AYRD220-1 cylinder on doors 1-3/4" or less in thickness, the tailpiece must be shortened per the below instructions. Failure to do so could result in damage to the housing assembly, and create binding during deadbolt operation.

1. Find the shear line as pictured here.
2. Line up the tailpiece shear line to the edge of the vise, as shown.
3. Use pliers to carefully shorten the tailpiece by bending at the shear line

